

High Efficient Electroshock-proof

Intelligent Ion Bar

AP-AB1207





Widely used in printing, UV flatbed industry

Social Contraction

17.00

Effectively solve the problem caused by static electricity





Static removal

Prevent adhesion of objects



Prevent sticking



Control ink splashing



Prevent uneven scattering









Safe





Static removal









Intelligent Control

Ion balance/ ion output frequency adjustable

The output ratio of positive and negative ions is adjustable, which can be used to adjust the ion balance voltage.



The output frequency of positive and negative ions is adjustable, which can be applied to different discharge distance to achieve faster discharge speed.



Intelligent Control

Ion balance/ ion output frequency adjustable





| | Button function instructions | | |
|--|-------------------------------|---------------------------|--|
| | Function | Symbol | Operation instructions |
| | Unlock | ß | Unlock before adjusting operating parameters. |
| + ок - | Run / Pause | | Device starts running when power is on. Press "STOP" to standby and no high voltage output. Press "RUN" again and the device will start working. |
| CTTH CAL ALTH PWM FREQ CFM IB> IBN IBV | Adjust cleaning cycle | $CT_{TH} \rightarrow +/-$ | Press CTTH first, then +/- to increase or decrease the cleaning cycle. The default cleaning period is 15 days, and the adjustment range is 1-60 days. The cleaning function will alarm when the countdown is 0 days. Power off and restart to restore the set time. The cleaning function becomes invalid if the value is set to 0 days. |
| 1 2 3 4 5 6 | Adjust frequency | $FREQ \rightarrow +/-$ | Press FREQ first, then press +/- to increase or decrease the frequency of positive and negative ions output . Note: this adjustment function can only be effective if the coding switch is in C or D position. |
| | Adjust ion balance voltage | $IB_N \to +/\text{-}$ | Press IB_N first, then press + when the positive voltage on flat panel detector or discharge object surface is high, press IB_N first, then press - when the negative voltage on flat panel detector or discharge object surface is high until the ion balance reaches the ideal status. |
| | Confirm | $CAL \rightarrow OK$ | Note: Press CAL first, then press OK to confirm after adjusting the output parameter; otherwise, false alarms are likely to occur. |

Pulse AC

The effect of static eliminating is better compare to power frequency AC ion bar

Comparison with traditional AC

Pulse AC Positive voltage working time Pulse AC +HV (Positive high pressure) Pulse AC + + + + 4 -HV (Negative high pressure) + + + + + -----Negative voltage working time e **e** e -e

Traditional AC



The pulsed AC method alternately applies "+" and "-" high voltage to one electrode needle to generate two polar ions.

Compared with the AC method, the ion generation efficiency is higher.Electrostatic elmiination ability can be fully plated on matter for short or long distance.Beside,frequency adjustable so the working distance extended.Positive and negative ion output ratio adjustable so easy for intelligent control.

Efficiently static removal

Stay away static trouble & for clean production environment



The test data diagram is as follows (test distance: 100mm, ion bar length: 410mm, working frequency: 30Hz):



Test data under other conditionsare as follows





÷

CE certification

It can effectively prevent the external electromagnetic interference from affecting the normal operation of the ion bar. This is a static electricity eliminator with high safety and high reliability.



Specification

Details / Parameter / Size

Product Details

Communication and DC24V power network port



Positive and negative high voltage indicator light (flashing alternately with frequency)



RJ45 port on the front panel of ion bar:

Green light for power on and orange light for communication connection on the left port; The orange light and the green light on the right port blink alternately with the working frequency; The green light works at positive high pressure, and the orange light works at negative high pressure.

Product Size



Ion bar size drawing

Mounting bracket size drawing

| Model | AP-AB1207 | |
|-----------------------|---|--|
| Input voltage | DC 24V | |
| Power | 10W | |
| Electrode pin voltage | Vpp:8-12KV | |
| Ion emission | Pulse AC | |
| Emitter electrode | SUS | |
| Discharge structure | Resistance coupling | |
| Output frequency | 0.1,0.5,1,5,10,30,55,65,105Hz; (EX-Work setting: 30Hz) | |
| Discharge range | L*W*H: Bar Length*300*100mm | |
| Installation distance | 30→100mm | |
| Ion balance | $\leq \pm 30V $ (AVE) | |
| Discharge speed | ≤1S (Test distance 100mm) | |
| Status indicator | Green light - normal, Blue light - standby, Blue light flashing—debugging /cleaning, Red light - Abnormal high voltage | |
| Working temperature | 0°C-50°C | |
| Working humidity | < 70% | |
| Dimensions(L*W*H) | {400mm-300mm(Needle spacing 50mm)*35mm*63.5mm | |
| Bar material | Flame retardant PVC, AL, SUS | |
| Packaging accessories | 180°rotatable mounting angle | |
| Power adapter | GRT-240200: DC24V 2A dual network port output ; L*W*H: 123*61*40.5mm | |
| Power cord | 2.5m | |
| Warranty | 1 year | |
| Certification | CE | |

Use of the product

Installation step / Installation position / Packaging accessories

Installation step







The adapter power indicator light is on and the ion bar panel indicator light is green to show that the ion bar is working. The positive and negative high voltage indicator lights alternately flash with the frequency. The front network port only lights orange-negative high voltage and the rear network port only lights green-positive high voltage.

| Power interface definition | | | | |
|----------------------------|---|--------------|---------|--|
| | 1 | Orange | +24VDC | |
| | 2 | white-orange | +24VDC | |
| | 3 | Blue | RS485+B | |
| | 4 | White-blue | RS485+A | |
| | 5 | Green | 0V | |
| | 6 | White-green | 0V | |
| - Hullandar | 7 | Brown | EGND | |
| | 8 | white-brown | EGND | |
| | 9 | Metal shield | PE | |



appropriate air pressure. When the positive voltage on the surface of the flat panel detector or the object to be discharged is large, press to adjust "IB-"; when the negative voltage on the flat panel detector or the surface of the object to be discharged is large, press "IB+" to adjust until the balance is adjusted to the ideal status.

Installation position

 Choose the best static elimination position and install the bar body and the matching power adapter firmlyafter the static detection of the on-site working environme. The installation angle should be perpendicular to the surface of the charged body and the installation distance can be referred to the following table. (Ex-work setting is 30Hz. Use the remote control to adjust if you need to adjust the output frequency. Configure a flat panel tester if you want to see the adjustment results).



- 2. The ion bar grounding electrode is not allowed to be covered by other objects.
- 3. It is advisable to install two ion bars side by side with an interval of more than 300mm. Two ion bars should be staggered by more than 300mm if they are to be installed face to face.



4. It is advisable to be more than 200mm away from obstacles such as walls.



5. For the safe use of the ion bar, the ion bar discharge electrode should be at least 30mm away from the metal conductor and metal grounding body and the bar body must be reliably connected to the grounding wire.



6. The installation angle of the ion bar can be adjusted.



| Name | Image | Part No. | Specification | Quantity |
|--|------------|-----------|---|----------|
| Power Adapter | | OSP000601 | GRT-240200: DC24V 2A, dual network port output, Size: 123*61*40.5mm (L*W*H) | 1 |
| National standard power cord | Ŷ | 8YXG25110 | Standard:1.8m, optional:3m/5m | 1 |
| Double ended crystal head black shield cable | | 8WXI00004 | Standard:2.5m, 5m/10m:optional | 1 |
| Single-ended crystal head black shield cable | -0. | 8WXI00002 | FUTP CAT.5E 26AWG 4Pair Jacket PVC OD:5.6±0.2mm | Optional |
| L-shaped stainless steel mounting bracket | (°) | AP8038005 | Height 25mm/Width 16mm/ Thickness 3mm Aperture 5mm (measured 4.8mm) | 4 |
| Square nut | O | AP8933000 | M5*12*12*4 | 2 |
| 304 stainless steel spring washer | Õ | AP8943000 | M5 | 6 |
| 304 stainless steel flat gasket | \bigcirc | AP8946004 | M5 | 6 |
| 304 stainless steel pan head Phillips screw | S | AP8900001 | M5*12 | 6 |
| Hex nuts | Ø | 1LML05000 | M5 | 4 |
| Intake throttle valve | | 3JTQF0801 | Standard:8mm, optional:6mm | 1 |
| Needle holder | | AP6604000 | | |
| Remote control | | AP2253011 | Infrared remote control, neutral panel (L*W*H: 85.76*39.76*6.66) | 1 |

🕂 Safety warning

- 1. Please read the instruction manual carefully before installing and using this equipment.
- 2. The whole set of equipment must be reliably grounded during use, otherwise it is easy to cause abnormality or even damage to the ion bar.
- 3. Do not use this equipment in environment where humidity is > 70%.
- 4. It is strictly forbidden to use this equipment in flammable and explosive environments.
- 5. Unauthorized disassembly of the product is strictly prohibited, internal maintenance and repair must be performed by professionals.
- 6. The product is strictly prohibited to touch liquid during use, otherwise an abnormality may occur and cause electric shock or fire.
- 7. Power must be turned off during inspecting or replacing the product, otherwise it may cause electric shock or fire.
- 8. The product is specially designed to eliminate static electricity. It is strictly forbidden to use it for other purposes. Any abnormal use may cause machine failure, electric shock, fire and other accidents.
- 9. Its strictly forbidden to touch the electrode needles when power is on, otherwise it is easy to cause malfunctions and electric shock accidents.
- 10. The electrode needle is a sharp metal object, please use it with care.
- 11.Please check the specifications of the power supply before powering on the product. Any power supply that does not meet the specifications will cause damage to the product.
- 12. Please check the product power cord/communication cord regularly and replace it immediately if it is damaged. Otherwise it is easy to cause problems such as electric leakage, poor communication, and abnormal operation.

\bigwedge Trouble shooting

| NO. | Faults | Reasons | Solutions | |
|--|--|---|---|--|
| NO. | Faults | Reasons | | |
| | | Poor contact of the power cable | Check whether the power cable is in good condition and securely connected | |
| | Power supply mismatch | Confirm the power supply specification (INPUT: 100—240VAC 50/60Hz; OUTPUT: 24VDC 2000mA) | | |
| | | No power supply and the left port green power indicator is off | Check the power supply line | |
| The RJ45 power port indicator 1 on the front panel is off | No communication connection or communication failure, the orange communication connection indicator on the left port is off | Check communication connection and software setup | | |
| | Wrong working mode - Only green light on at the right port (positive high voltage only) | Unplug the power cord and restart the ion bar. Or reset the working frequency (this lamp is not used to judge the failure of the high | | |
| | Wrong working mode Only orange light on at the right port (negative high voltage only) | voltage module) | | |
| | The duty ratio is too small and the green light is dark | Adjust duty ratio until ion balance becomes good. Return to factory | | |
| | | The duty ratio is too high and the orange light is dark | for repair if adjustment is not effective. | |
| | 2 The electrostatic removal performance decreased obviously | Discharge needle is polluted and damaged | Clean or replace the discharge needle | |
| 2 | | Whether the discharge seat is tightened | Confirm the discharge seat is tightened | |
| | | Ion bar positioning is incorrect | Confirm the best installation location | |
| 3 | The electrostatic removal performance decreased | There are conductors or other ion bar around | Remove (moving) conductors or other ion bar | |
| | | Electromagnetic interference | Turn off the power switch / unplug the power cable, restart the ion bar | |
| 4 | High voltage alarm 4 (Panel indicator red light on) | Abnormal discharge | Confirm the installation location and stay away from surrounding conductors | |
| 4 | | No power supply for high voltage module | Return to factory for maintenance | |
| | High voltage module is damaged | Return to factory for maintenance | | |
| | 5 Unable to discharge | High voltage module is damaged | Return to factory for maintenance | |
| 5 | | Main-board chip is damaged | Return to factory for maintenance | |
| | Main-board chip is damaged caused by poor grounding or no grounding | Check the grounding of the ion bar and plant equipment, and return to factory for maintenance | | |
| 6 | The product is smoky or burnt | High voltage module is damaged or insulation of the discharge seat is damaged | Return to factory for maintenance | |

🕂 Maintenance

 The ion bar should be cleaned and maintained in time according to the use environment and the required electrostatic protection requirements in order to ensure the good performance of the product. That is, gently remove the carbon deposits on the discharge electrode, discharge socket, and metal discharge body with electrostatic brush, dust-free cotton swab, dust-free cloth dipped in anhydrous alcohol, which will improve its performance significantly. Note:

A. Operation must be done 10 minutes after power cut off.

B. It must be cleaned when dust or white products appear on the tip of the needle during use. Use dust-free cloth dipped in anhydrous alcohol to clean when brush can not meet the cleaning requirements.

C. The ion bar must be powered on after alcohol is completely volatilized after cleaning. No other organic solvent can be used to clean the ion bar.

2. If the switch working indicator light of the power plug-in port on the panel of the ion bar is off, it should be stopped and repaired by professional maintenance personnel. It can be used only after the electrical performance index is normal.

⚠ After-sales service

AP-AB1207 has undergone rigorous testing and aging treatment before ex-work. Its performance has completely reached the relevant indicators marked in the usage instruction.

- 1. AP&T makes a commitment to the customer that any defective parts inspected by AP&T will be repaired or replaced free of charge within one year from the date of purchase. However, this commitment does not apply to:
 - (1) The device is incorrectly used or installed.
 - (2) Damage caused by negligence or accident during use.
- (3) Modified, disassembled or repaired by other service departments not authorized by Anping Company.
- 2. The alloy electrode is a consumable product which is not included in the scope of warranty and will be charged for replacement when repairing.
- 3. AP&T shall not be liable for any incorrect use of the products except for repair or replacement of parts as specified above.



Speciality Creates Value

Shanghai Anping Static Technology Co.,Ltd

Tel : 021-64517676 Fax : 021-64517673 Postcode : 200233 Website : www.ap-static.com Address : 3/F,Building 27,No.69,Guiqing Road,Shanghai,China

